

Application recommendation: Polishing the new Adamant High Gloss Lacquer

1 Matting and smoothing

Rough with Abranet 150 mm P 1000

Tip: Position equally on the surface so as to minimise the risk of over-sanding.



2 Minimising the roughness depth

Polarstar 150 mm P 1500 with extraction (dry sanding)

Tip: Use a 5 mm soft pad to prevent clogging and absorb the pressure away from the surface.



3 Polishing

Polish the surface with the Mirka lambswool pad in combination with Polarshine 35 polishing compound and an electric polisher.

Important: Beware of the surface getting hot.



4 High gloss finish

To obtain the final high gloss finish, use the black PRO foam pad in combination with Polarshine 8 polishing compound and an electric polisher.

